

DENSO



DST-PC

Version 6.1.0
DIESEL ENGINES

Additional
Required
Diagnostic
Cable



K-Type

Manage Projects	Read and Delete Trouble Codes and Freeze Frame Data	Live Data Parameter Monitor	Perform Active Test	Utility Menu (examples: Pump & Pilot Quantity (Detail) Learning, Injector Programming, Crank time - & A/F sensor Compensation)	Help (DST-PC Operation Manual)	Diagnosis Manual

Make	Model	Engine	Displacement	Model Year	Info									
Mazda														
Mazda	323 / Familia (BJ)	RF-MDT	2.0L D	09/1998 - 05/2004	52kW / 71HP	951711-1840	9910	V5.1.0	V5.1.0	V5.1.0	V5.1.0	N/A	V5.1.0	
Mazda	323 / Familia (BJ)	RF1G	2.0L D	09/1998 - 05/2004	52kW / 71HP	951711-1840	9912	V5.1.0	V5.1.0	V5.1.0	V5.1.0	N/A	V5.1.0	
Mazda	323 / Familia (BJ)	RF-MDT	2.0L TD	09/1998 - 01/2001	66kW / 90HP	951711-1840	9911	V5.1.0	V5.1.0	V5.1.0	V5.1.0	N/A	V5.1.0	
Mazda	323 / Familia (BJ)	RF-MDT	2.0L TD	09/1998 - 01/2001	66kW / 90HP	951711-1840	9913	V5.1.0	V5.1.0	V5.1.0	V5.1.0	N/A	V5.1.0	
Mazda	323 / Familia (BJ)	RF4F	2.0L DiTD	01/2001 - 05/2004	74kW / 101HP	951711-1840	20654	V5.1.0	V5.1.0	V5.1.0	V5.1.0	N/A	V5.1.0	
Mazda	323 / Familia (BJ)	RF4F	2.0L TD	01/2001 - 05/2004	74kW / 101HP	951711-1840	15793	V5.1.0	V5.1.0	V5.1.0	V5.1.0	N/A	V5.1.0	
Mazda	626 / Capella (GF) Estate/Break/Station Wagon	RF3F	2.0L DTD	04/1998 - 10/2002	66kW / 90HP	951711-1840	19180	V5.1.0	V5.1.0	V5.1.0	V5.1.0	N/A	V5.1.0	
Mazda	626 / Capella (GF) Estate/Break/Station Wagon	RF4F	2.0L Turbo Di	04/1998 - 10/2002	74kW / 101HP	951711-1840	10262	V5.1.0	V5.1.0	V5.1.0	V5.1.0	N/A	V5.1.0	
Mazda	626 / Capella (GF) Estate/Break/Station Wagon	RF-MDT	2.0L TD	10/2000 - 10/2002	81kW / 110HP	951711-1840	17315	V5.1.0	V5.1.0	V5.1.0	V5.1.0	N/A	V5.1.0	
Mazda	626 / Capella (GW) Estate/Break/Station Wagon	RF3F	2.0L DiTD	09/1999 - 10/2002	66kW / 90HP	951711-1840	18722	V5.1.0	V5.1.0	V5.1.0	V5.1.0	N/A	V5.1.0	
Mazda	626 / Capella (GW) Estate/Break/Station Wagon	RF4F	2.0L Turbo Di	04/1998 - 10/2002	74kW / 101HP	951711-1840	10263	V5.1.0	V5.1.0	V5.1.0	V5.1.0	N/A	V5.1.0	
Mazda	626 / Capella (GW) Estate/Break/Station Wagon	RF-MDT	2.0L TD	10/2000 - 10/2002	81kW / 110HP	951711-1840	17316	V5.1.0	V5.1.0	V5.1.0	V5.1.0	N/A	V5.1.0	
Mazda	CX-7 (ER)	MZR-CD	2.2L	09/2009+	127kW / 173HP		32111	V5.1.0	V5.1.0	V5.1.0	V5.1.0	V5.1.0	V5.1.0	
Mazda	Mazda3 (BK)	RF7J MZR-CD	2.0L	12/2006+	105kW / 143HP		26586	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.1.0
Mazda	Mazda3 (BL)	MZR-CD	2.2L	06/2009+	110kW / 150HP		31078	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.1.0
Mazda	Mazda3 (BL)	MZR-CD	2.2L	06/2009+	136kW / 185HP		31079	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.1.0
Mazda	Mazda3 (BK) Saloon	RF7J MZR-CD	2.0L	12/2006+	105kW / 143HP		26587	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.1.0
Mazda	Mazda3 (BL) Saloon	MZR-CD	2.2L	06/2009+	110kW / 150HP		33443	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.1.0
Mazda	Mazda3 (BL) Saloon	MZR-CD	2.2L	06/2009+	136kW / 185HP		33444	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.1.0
Mazda	Mazda5 (CR19)	MZR-CD	2.0L CD	03/2005+	81kW / 110HP		18545	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.1.0
Mazda	Mazda5 (CR19)	RF7J MZR-CD	2.0L CD	06/2005+	105kW / 143HP		18830	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.1.0
Mazda	Mazda6 / Atenza (GG) Saloon	RF5C MZR-CD	2.0L DI	08/2002+	89kW / 121HP		16865	V3.0.1	V3.0.1	V3.0.1	V3.0.1	V3.0.1	V3.0.1	V3.1.0
Mazda	Mazda6 / Atenza (GG) Saloon	RF5C MZR-CD	2.0L DI	06/2002+	100kW / 136HP		16687	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0
Mazda	Mazda6 / Atenza (GG) Saloon	RF7J MZR-CD	2.0L DI	06/2005+	105kW / 143HP		18828	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.1.0
Mazda	Mazda6 (GH) Saloon	MZR-CD	2.0L	08/2007+	103kW / 140HP		25460	V4.0.0	V4.0.0	V4.0.0	V5.0.0	V5.0.0	V4.0.0	V5.0.0
Mazda	Mazda6 (GH) Saloon	MZR-CD	2.2L	01/2009+	92kW / 125HP		30888	V4.0.0	V4.0.0	V4.0.0	V5.0.0	V5.0.0	V4.0.0	V5.1.0
Mazda	Mazda6 (GH) Saloon	MZR-CD	2.2L	01/2009+	120kW / 163HP		30889	V4.0.0	V4.0.0	V4.0.0	V5.0.0	V5.0.0	V4.0.0	V5.1.0
Mazda	Mazda6 (GH) Saloon	MZR-CD	2.2L	01/2009+	136kW / 185HP		30890	V4.0.0	V4.0.0	V4.0.0	V5.0.0	V5.0.0	V4.0.0	V5.1.0
Mazda	Mazda6 (GH) Combi-Coupe/Estate/Sport Kombi	MZR-CD	2.0L	02/2008+	103kW / 140HP		28152	V4.0.0	V4.0.0	V4.0.0	V5.0.0	V5.0.0	V4.0.0	V5.1.0
Mazda	Mazda6 (GH) Combi-Coupe/Estate/Sport Kombi	MZR-CD	2.2L	01/2009+	92kW / 125HP		30894	V4.0.0	V4.0.0	V4.0.0	V5.0.0	V5.0.0	V4.0.0	V5.1.0
Mazda	Mazda6 (GH) Combi-Coupe/Estate/Sport Kombi	MZR-CD	2.2L	01/2009+	120kW / 163HP		30895	V4.0.0	V4.0.0	V4.0.0	V5.0.0	V5.0.0	V4.0.0	V5.1.0
Mazda	Mazda6 (GH) Combi-Coupe/Estate/Sport Kombi	MZR-CD	2.2L	01/2009+	136kW / 185HP		30896	V4.0.0	V4.0.0	V4.0.0	V5.0.0	V5.0.0	V4.0.0	V5.1.0
Mazda	Mazda6 / Atenza (GG) Hatchback	RF5C MZR-CD	2.0L DI	08/2002+	89kW / 121HP		16844	V3.0.1	V3.0.1	V3.0.1	V3.0.1	V3.0.1	V3.0.1	V3.1.0
Mazda	Mazda6 / Atenza (GG) Hatchback	RF5C MZR-CD	2.0L DI	08/2002+	100kW / 136HP		16683	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0
Mazda	Mazda6 / Atenza (GG) Hatchback	RF7J MZR-CD	2.0L DI	06/2005+	105kW / 143HP		18827	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.1.0
Mazda	Mazda6 (GH) Hatchback/Sport	MZR-CD	2.0L	08/2007+	103kW / 140HP		25464	V4.0.0	V4.0.0	V4.0.0	V5.0.0	V5.0.0	V4.0.0	V5.0.0
Mazda	Mazda6 (GH) Hatchback/Sport	MZR-CD	2.2L	01/2009+	92kW / 125HP		30893	V4.0.0	V4.0.0	V4.0.0	V5.0.0	V5.0.0	V4.0.0	V5.1.0
Mazda	Mazda6 (GH) Hatchback/Sport	MZR-CD	2.2L	01/2009+	120kW / 163HP		30892	V4.0.0	V4.0.0	V4.0.0	V5.0.0	V5.0.0	V4.0.0	V5.1.0
Mazda	Mazda6 (GH) Hatchback/Sport	MZR-CD	2.2L	01/2009+	136kW / 185HP		30891	V4.0.0	V4.0.0	V4.0.0	V5.0.0	V5.0.0	V4.0.0	V5.1.0
Mazda	Mazda6 / Atenza (GY) Station Wagon, Estate	RF5C MZR-CD	2.0L DI	08/2002+	89kW / 121HP		16864	V3.0.1	V3.0.1	V3.0.1	V3.0.1	V3.0.1	V3.0.1	V3.1.0
Mazda	Mazda6 / Atenza (GY) Station Wagon, Estate 4x4	RF5C MZR-CD	2.0L CiTD	10/2002 - 02/2005	89kW / 121HP		27986	V3.0.1	V3.0.1	V3.0.1	V3.0.1	V3.0.1	V3.0.1	V3.1.0
Mazda	Mazda6 / Atenza (GY) Station Wagon, Estate	RF5C MZR-CD	2.0L DI	08/2002+	100kW / 136HP		16691	V3.0.1	V3.0.1	V3.0.1	V3.0.1	V3.0.1	V3.0.1	V3.1.0
Mazda	Mazda6 / Atenza (GY) Station Wagon, Estate	RF7J MZR-CD	2.0L DI	06/2005+	105kW / 143HP		18829	V4.0.0	V4.0.0	V4.0.0	V5.0.0	V5.0.0	V4.0.0	V5.1.0
Mazda	Mazda6 / Atenza (GY) Station Wagon, Estate 4x4	RF5C MZR-CD	2.0L CiTD	10/2002 - 02/2005	100kW / 136HP		27987	V3.0.1	V3.0.1	V3.0.1	V3.0.1	V3.0.1	V3.0.1	V3.1.0
Mazda	MPV II (LW)	RF5C MZR-CD	2.0L DI	07/2002+	100kW / 136HP		16857	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0
Mazda	MPV II (LW)	RF5C MZR-CD	2.0L DI	07/2002+	89kW / 121HP			V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0
Mazda	Premacy (CP)	RF3F	2.0L TD	10/1999 - 07/2000	66kW / 90HP	951711-1840	14493	V5.1.0	V5.1.0	V5.1.0	V5.1.0	N/A	V5.1.0	
Mazda	Premacy (CP)	RF4F	2.0L TD	07/2000+	74kW / 101HP	951711-1840	15800	V5.1.0	V5.1.0	V5.1.0	V5.1.0	N/A	V5.1.0	











DST-PC

Version 6.1.0
DIESEL ENGINES

Additional
Required
Diagnostic
Cable



						
Manage Projects	Read and Delete Trouble Codes and Freeze Frame Data	Live Data Parameter Monitor	Perform Active Test	Utility Menu (examples: Pump & Pilot Quantity (Detail) Learning, Injector Programming, Crank time - & A/F sensor Compensation)	Help (DST-PC Operation Manual)	Diagnosis Manual

Make	Model	Engine	Displacement	Model Year	Info	Additional Required Diagnostic Cable	K-Type	Manage Projects	Read and Delete Trouble Codes and Freeze Frame Data	Live Data Parameter Monitor	Perform Active Test	Utility Menu (examples: Pump & Pilot Quantity (Detail) Learning, Injector Programming, Crank time - & A/F sensor Compensation)	Help (DST-PC Operation Manual)	Diagnosis Manual
Mitsubishi														
Mitsubishi	Canter	4D34T6		06/2001+					DST-1	DST-1	DST-1	N/A		
Mitsubishi	Canter	4D34T6		11/2000+					DST-1	DST-1	DST-1	N/A		
Mitsubishi	Canter	4D34T6		12/2001+					DST-1	DST-1	DST-1	N/A		
Mitsubishi	Galant MkVI (EA_) Saloon	4D68	2.0L TDI	09/1996 - 10/2004	66kW / 90HP		7847		DST-1	DST-1	DST-1	N/A		
Mitsubishi	Galant MkVI (EA6W) Estate	4D68	2.0L TDI	09/1996 - 10/2003	66kW / 90HP		7850		DST-1	DST-1	DST-1	N/A		
Mitsubishi	L200 / Triton Pickup	4D56	2.5L DI-D	10/2007+	123kW / 167HP		24544	V5.1.0	V5.1.0	V6.1.0	V6.1.0	V6.1.0	V5.1.0	V6.1.0
Mitsubishi	L200 / Triton Pickup (RWD)	4D56	2.5L DI-D	04/2010+	94kW / 128HP		33129	V5.1.0	V5.1.0	V6.1.0	V6.1.0	V6.1.0	V5.1.0	V6.1.0
Mitsubishi	L200 / Triton Pickup (RWD)	4D56	2.5L DI-D	11/2005+	100kW / 136HP		28517	V5.1.0	V5.1.0	V6.1.0	V6.1.0	V6.1.0	V5.1.0	V6.1.0
Mitsubishi	L200 / Triton Pickup (RWD)	4D56	2.5L DI-D	11/2005+	100kW / 136HP		19365	V5.1.0	V5.1.0	V6.1.0	V6.1.0	V6.1.0	V5.1.0	V6.1.0
Mitsubishi	L200 / Triton Pickup 4x4	4D56	2.5L DI-D	04/2010+	131kW / 178HP		33130	V5.1.0	V5.1.0	V6.1.0	V6.1.0	V6.1.0	V5.1.0	V6.1.0
Mitsubishi	Pajero / Montero / Shogun IV (V80, V90)	4M41	3.2L TD	01/2009+	147kW / 200HP		33209	V5.1.0	V5.1.0	V6.1.0	V6.1.0	V6.1.0	V5.1.0	V5.1.0
Mitsubishi	Pajero / Montero / Shogun IV (V80, V90)	4M41	3.2L DI-D	02/2007+	118kW / 160HP		22653	V5.1.0	V5.1.0	V6.1.0	V6.1.0	V6.1.0	V5.1.0	V5.1.0
Mitsubishi	Pajero / Montero / Shogun IV (V80, V90)	4M41	3.2L DI-D	02/2007+	125kW / 170HP		22654	V5.1.0	V5.1.0	V6.1.0	V6.1.0	V6.1.0	V5.1.0	V5.1.0
Mitsubishi	Pajero / Montero / Shogun Sports	4D56	2.5L DI-D	06/2009+				V5.1.0	V5.1.0	V6.1.0	V6.1.0	V6.1.0	V5.1.0	
Mitsubishi	Pajero / Montero / Shogun Sports	4M41	3.2L DI-D	03/2008+				V5.1.0	V5.1.0	V6.1.0	V6.1.0	V6.1.0	V5.1.0	V6.1.0
Mitsubishi	Space Runner	4D68		07/1996+					DST-1	DST-1	DST-1	N/A		



**Additional
Required
Diagnostic
Cable**



Make	Model	Engine	Displacement	Model Year	Info	Diagnostic Cable	K-Type	Man	Read and	Live	Perfom	Utiliti (ear, Prog)	Help (DS)	Diagn
Nissan														
Nissan	Almera / Pulsar II (N16) Hatchback	YD22DDT	2.2L dCi	03/2000+	81kW / 110HP		14659	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0
Nissan	Almera / Pulsar II (N16) Hatchback	YD22DDT	2.2L dCi	09/2003+	82kW / 112HP		17681	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0
Nissan	Almera / Pulsar II (N16) Hatchback	YD22DDTi	2.2L dCi	09/2003+	100kW / 136HP		17682	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0
Nissan	Almera / Pulsar II (N16) Saloon	YD22DDT	2.2L dCi	07/2000+	81kW / 110HP		14916	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0
Nissan	Almera / Pulsar II (N16) Saloon	YD22DDT	2.2L dCi	09/2003+	82kW / 112HP		17683	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0
Nissan	Almera / Pulsar II (N16) Saloon	YD22DDTi	2.2L dCi	09/2003+	100kW / 136HP		17684	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0
Nissan	Almera Tino (V10)	YD22DDT	2.2L dCi	09/2003+	82kW / 112HP		17685	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0
Nissan	Almera Tino (V10)	YD22DDTi	2.2L dCi	08/2000+	84kW / 115HP		14917	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0
Nissan	Almera Tino (V10)	YD22DDTi	2.2L dCi	09/2003+	100kW / 136HP		17686	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0
Nissan	Cabstar (F24) 28.11	YD25	2.5L	10/2006+	81kW / 110HP			V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.1.0
Nissan	Cabstar (F24) 35.13	YD25	2.5L	10/2006+	96kW / 131HP			V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.1.0
Nissan	Cabstar (F24) 45.13	YD25	2.5L	10/2006+	96kW / 131HP			V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.1.0
Nissan	Navara / Frontier (D40) 4WD Flatbed / Chassis	YD25	2.5L	08/2008+	126 kW / 171 HP		33564	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0
Nissan	Navara / Frontier (D40) 4WD Flatbed / Chassis	YD25	2.5L	08/2008+	106 kW / 144 HP		33565	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0
Nissan	Navara / Frontier (D40) 4WD Pickup	YD25	2.5L	10/2006+	126 kW / 171 HP		23054	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0
Nissan	Navara / Frontier (D40) 4WD Pickup	YD25DDTi	2.5L	07/2005+	128 kW / 174 HP		18795	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0
Nissan	Navara / Frontier (D40) Pickup	YD25DDTi	2.5L	07/2005+	106 kW / 144 HP		18794	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0
Nissan	Navara / Frontier (D40) Pickup	YD25DDTi	2.5L	12/2005+	128 kW / 174 HP		33529	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0
Nissan	Pathfinder / Xterra (R51)	YD25DDTi	2.5L	01/2005+	128 kW / 174 HP		20643	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0
Nissan	Pathfinder / Xterra (R51) 4WD	YD25	2.5L	10/2006+	126 kW / 171 HP		23053	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0
Nissan	Pathfinder / Xterra (R51) 4WD	YD25DDTi	2.5L	03/2005+	128 kW / 174 HP		18506	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0
Nissan	Primera (P12) Hatchback	YD22DDT	2.2L	03/2002+	93 kW / 126 HP		16924	V5.0.0	V5.0.0	V5.0.0	V5.0.0	N/A	V5.0.0	V6.1.0
Nissan	Primera (WP12) Estate/Traveller	YD22DDT	2.2L	04/2003+	102 kW / 139 HP		17540	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0
Nissan	Primera (P12) Hatchback	YD22DDT	2.2L	04/2003+	102 kW / 139 HP		17543	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0
Nissan	Primera (WP12) Estate/Traveller	YD22DDT	2.2L	03/2002+	93 kW / 126 HP		16277	V5.0.0	V5.0.0	V5.0.0	V5.0.0	N/A	V5.0.0	V6.1.0
Nissan	Primera (P12) Saloon	YD22DDT	2.2L	03/2002+	93 kW / 126 HP		16274	V5.0.0	V5.0.0	V5.0.0	V5.0.0	N/A	V5.0.0	V6.1.0
Nissan	Primera (P12) Saloon	YD22DDT	2.2L	04/2003+	102 kW / 139 HP		17541	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0
Nissan	X-Trail (T30)	YD22DDTi	2.2L	06/2001 - 09/2003	84 kW / 114 HP		24628	V5.0.0	V5.0.0	V5.0.0	V5.0.0	N/A	V5.0.0	V6.1.0
Nissan	X-Trail (T30)	YD22DDTi	2.2L	10/2004+	84 kW / 114 HP		21557	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0
Nissan	X-Trail (T30)	YD22DDTi	2.2L	12/2003+	100 kW / 136 HP		19070	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0
Nissan	X-Trail (T30) 4x4	YD22DDTi	2.2L	07/2001+	84 kW / 114 HP		15970	V5.0.0	V5.0.0	V5.0.0	V5.0.0	N/A	V5.0.0	V6.1.0
Nissan	X-Trail (T30) 4x4	YD22DDTi	2.2L	12/2003+	100 kW / 136 HP		17887	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0
Nissan	X-Trail (T31)	M9R	2.0L	06/2007+	110 kW / 150 HP		23198	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0
Nissan	X-Trail (T31)	M9R 760	2.0L	06/2007+	127 kW / 173 HP		23196	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0
Nissan	X-Trail (T31) FWD	?	2.0L dCi	06/2007+	110 kW / 150 HP		4471	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0

DENSO



DST-PC

Version 6.1.0
DIESEL ENGINES

Additional
Required
Diagnostic
Cable



K-Type

Manage Projects	Read and Delete Trouble Codes and Freeze Frame Data	Live Data Parameter Monitor	Perform Active Test	Utility Menu (examples: Pump & Pilot Quantity (Detail) Learning, Injector Programming, Crank time - & A/F sensor Compensation)	Help (DST-PC Operation Manual)	Diagnosis Manual

Make	Model	Engine	Displacement	Model Year	Info									
Opel / Vauxhall														
Opel / Vauxhall	Astra-G Estate	Y17DT	1.7L DTI 16V	02/2000 - 07/2004	55 kW / 75 HP		14182	V5.0.0	V5.0.0	V5.0.0	V5.0.0	N/A	V5.0.0	
Opel / Vauxhall	Astra-G Hatchback	Y17DT	1.7L DTI 16V	02/2000 - 01/2005	55 kW / 75 HP		13860	V5.0.0	V5.0.0	V5.0.0	V5.0.0	N/A	V5.0.0	
Opel / Vauxhall	Astra-G Saloon	Y17DT	1.7L DTI 16V	02/2000 - 01/2005	55 kW / 75 HP		13861	V5.0.0	V5.0.0	V5.0.0	V5.0.0	N/A	V5.0.0	
Opel / Vauxhall	Astra-H	A17DTJ	1.7L CDTI	02/2007+	81 kW / 110 HP		22686	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.1.0
Opel / Vauxhall	Astra-H	Z17DTH	1.7L CDTI	03/2004+	74kW / 100HP		17848	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	
Opel / Vauxhall	Astra-H	Z17DTJ / A17DTJ	1.7L CDTI	02/2007+	81 kW / 110 HP		22688	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.1.0
Opel / Vauxhall	Astra-H Estate	A17DTR	1.7L CDTI	02/2007+	92 kW / 125 HP		22691	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.1.0
Opel / Vauxhall	Astra-H Estate	Z17DTH	1.7L CDTI	08/2004+	74kW / 101HP		18079	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	
Opel / Vauxhall	Astra-H GTC Hatchback	A17DTJ	1.7L CDTI	02/2007+	81 kW / 110 HP		22687	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.1.0
Opel / Vauxhall	Astra-H GTC Hatchback	A17DTR	1.7L CDTI	02/2007+	92 kW / 125 HP		22690	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.1.0
Opel / Vauxhall	Astra-H GTC Hatchback	Z17DTH	1.7L CDTI	03/2005+	74kW / 101HP		18299	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	
Opel / Vauxhall	Astra-H Hatchback	Z17DTR	1.7L CDTI	02/2007+	92 kW / 125 HP		22689	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.1.0
Opel / Vauxhall	Astra-H Saloon	Z17DTH	1.7L CDTI	02/2007+	74kW / 100HP		30935	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	
Opel / Vauxhall	Combo Box Body / Estate	Y17DT	1.7L DTI 16V	10/2001+	55 kW / 75 HP		16208	V5.0.0	V5.0.0	V5.0.0	V5.0.0	N/A	V5.0.0	
Opel / Vauxhall	Combo Box Body / Estate	Y17DTL	1.7L DI 16V	10/2001+	48 kW / 65 HP		16191	V5.0.0	V5.0.0	V5.0.0	V5.0.0	N/A	V5.0.0	
Opel / Vauxhall	Combo Box Body / Estate	Z17DTH	1.7L CDTI 16V	12/2004+	74 kW / 100 HP		19948	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0
Opel / Vauxhall	Combo Tour	Y17DT	1.7L DTI 16V	10/2001+	55 kW / 75 HP		17262	V5.0.0	V5.0.0	V5.0.0	V5.0.0	N/A	V5.0.0	
Opel / Vauxhall	Combo Tour	Y17DTL	1.7L DI 16V	10/2001+	48 kW / 65 HP		17261	V5.0.0	V5.0.0	V5.0.0	V5.0.0	N/A	V5.0.0	
Opel / Vauxhall	Combo Tour	Z17DTH	1.7L CDTI 16V	12/2004+	74 kW / 100 HP		23132	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0
Opel / Vauxhall	Corsa-C Box	Y17DT	1.7L DTI 16V	09/2000+	55 kW / 75 HP		16195	V5.0.0	V5.0.0	V5.0.0	V5.0.0	N/A	V5.0.0	
Opel / Vauxhall	Corsa-C Box	Y17DTL	1.7L DI 16V	09/2000+	48 kW / 65 HP		16194	V5.0.0	V5.0.0	V5.0.0	V5.0.0	N/A	V5.0.0	
Opel / Vauxhall	Corsa-C Box	Z17DTH	1.7L CDTI	08/2003+	74 kW / 101 HP		27981	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0
Opel / Vauxhall	Corsa-C Hatchback	Y17DT	1.7L DTI	09/2000+	55 kW / 75 HP		14913	V5.0.0	V5.0.0	V5.0.0	V5.0.0	N/A	V5.0.0	
Opel / Vauxhall	Corsa-C Hatchback	Y17DTL	1.7L DI	09/2000+	48 kW / 65 HP		14914	V5.0.0	V5.0.0	V5.0.0	V5.0.0	N/A	V5.0.0	
Opel / Vauxhall	Corsa-C Hatchback	Z17DTH	1.7L CDTI	06/2003+	74 kW / 100 HP		17697	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0
Opel / Vauxhall	Corsa-D Hatchback	Z17DTR	1.7L CDTI	07/2006+	92 kW / 125 HP		19727	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.1.0
Opel / Vauxhall	Meriva-A	Y17DT	1.7L DTI	09/2003+	55 kW / 75 HP		16842	V5.0.0	V5.0.0	V5.0.0	V5.0.0	N/A	V5.0.0	
Opel / Vauxhall	Meriva-A	Z17DT	1.7L	09/2006+	74 kW / 100 HP			V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.1.0
Opel / Vauxhall	Meriva-A	Z17DTH	1.7L CDTI	09/2003+	74 kW / 100 HP		17205	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0
Opel / Vauxhall	Meriva-A	Z17DTR / A17DTR	1.7L CDTI	09/2006+	92 kW / 125 HP		19934	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.1.0
Opel / Vauxhall	Signum	Y30DT	3.0L V6 CDTI	05/2003+	130 kW / 177 HP		17212		DST-1	DST-1	DST-1			
Opel / Vauxhall	Vectra-C	Y30DT	3.0L V6 CDTI	06/2003+	130 kW / 177 HP		17605		DST-1	DST-1	DST-1			
Opel / Vauxhall	Vectra-C Estate	Y30DT	3.0L V6 CDTI	10/2003+	130 kW / 177 HP		17647		DST-1	DST-1	DST-1			
Opel / Vauxhall	Vectra-C GTS	Y30DT	3.0L V6 CDTI	06/2003+	130 kW / 177 HP		17604		DST-1	DST-1	DST-1			
Opel / Vauxhall	Zafira-B MPV	A17DTJ	1.7L CDTI	01/2008+	81 kW / 110 HP		25502	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.1.0
Opel / Vauxhall	Zafira-B MPV	A17DTR	1.7L CDTI	01/2008+	92 kW / 125 HP		25503	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.1.0

Peugeot														
Peugeot	Boxer3 / Relay3 100 Box/Van	4HU/4HV DCU102	2.2L HDi	04/2006+	74 kW / 101 HP	DSTPC0-0004 (*1)	19871	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V6.1.0
Peugeot	Boxer3 / Relay3 100 Bus	4HU/4HV DCU102	2.2L HDi	04/2006+	74 kW / 101 HP	DSTPC0-0004 (*1)	19868	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V6.1.0
Peugeot	Boxer3 / Relay3 100 Flatbed / Chassis	4HU/4HV DCU102	2.2L HDi	04/2006+	74 kW / 101 HP	DSTPC0-0004 (*1)	19874	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V6.1.0
Peugeot	Boxer3 / Relay3 120 Box/Van	4HU/4HV DCU102	2.2L HDi	04/2006+	88 kW / 120 HP	DSTPC0-0004 (*1)	19872	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V6.1.0
Peugeot	Boxer3 / Relay3 120 Bus	4HU/4HV DCU102	2.2L HDi	04/2006+	88 kW / 120 HP	DSTPC0-0004 (*1)	19869	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V6.1.0
Peugeot	Boxer3 / Relay3 120 Flatbed / Chassis	4HU/4HV DCU102	2.2L HDi	04/2006+	88 kW / 120 HP	DSTPC0-0004 (*1)	19875	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V6.1.0

Renault														
Renault	Espace IV (JK0/1_) (JK0JAB, JK0JCB)	P9X 701	3.0L V6 dCi	11/2002+	130kW / 177HP		17097	V6.0.0	V6.0.0	V6.0.0	V6.0.0	N/A	V6.0.0	
Renault	Vel Satis (BJ0_ Phase I)	P9X 701	3.0L V6 dCi	06/2002 - 05/2006	130kW / 177HP		16423	V5.1.0	V5.1.0	V5.1.0	V5.1.0	N/A	V5.1.0	



**Additional
Required
Diagnostic
Cable**



Make	Model	Engine	Displacement	Model Year	Info	Diagnostic Cable	K-Type	Man	Read and	Live	Perf	Utili (exa, Prog)	Heis (DS)	Dag
Subaru														
Subaru	Forester (SH)	H4DOTC	2.0L D	09/2008+	108kW / 147HP		30815	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0
Subaru	Forester	H4DOTC	2.0L D	12/2010+				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Subaru	Impreza	H4DOTC	2.0L D	01/2009+	110kW / 150HP		30897	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0
Subaru	Impreza	H4DOTC	2.0L D	2010+				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Subaru	Legacy IV	H4DOTC	2.0L D	02/2008+	110kW / 150HP		30819	V3.2.0	V3.2.0	V3.2.0	V3.2.0	V3.2.0	V3.2.0	V3.2.0
Subaru	Legacy V	H4DOTC	2.0L D	09/2009+	110kW / 150HP		32126	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Subaru	Legacy V Estate	H4DOTC	2.0L D	09/2009+	110kW / 150HP		32127	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Subaru	Outback	H4DOTC	2.0L D	09/2008+	110kW / 150HP		30719	V3.2.0	V3.2.0	V3.2.0	V3.2.0	V3.2.0	V3.2.0	V3.2.0
Suzuki														
Suzuki	Grand Vitara / Escudo (FT, GT, INC XL-7)		RF-Ti	2.0L TD Intercooler	03/1998+	64kW / 87HP		11518		DST-1	DST-1	DST-1	N/A	
Toyota														
Toyota	4Runner	2KD-FTV	2.5L	07/2005+				V6.0.0	V6.0.0	V6.0.0	V6.0.0	V6.0.0	V6.0.0	
Toyota	4Runner	2KD-FTV	2.5L	08/2001+				V6.0.0	V6.0.0	V6.0.0	V6.0.0	V6.0.0	V6.0.0	
Toyota	4Runner / Hilux Surf / Surf All-wheel Drive (_ N130)	1KZ-TE	3.0L Tdi	09/2000 - 07/2002	103kW / 140HP		30023	V6.0.0	V6.0.0	V6.0.0	V6.0.0	V6.0.0	V6.0.0	
Toyota	4Runner All-wheel Drive	1KZ-TE	3.0L Tdi	09/2000 - 07/2002	103kW / 140HP		30123	V6.0.0	V6.0.0	V6.0.0	V6.0.0	V6.0.0	V6.0.0	
Toyota	Auris (ADE15#) Hatchback	1AD-FTV	2.0L	03/2007+	94kW / 126HP		22466	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0
Toyota	Auris (ADE15#) Hatchback	1AD-FTV	2.0L 200MPa (CCo)	03/2009+	94kW / 126HP			V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V5.1.0
Toyota	Auris (ADE15#) Hatchback	1AD-FTV	2.0L 200MPa (DPF)	03/2009+	94kW / 126HP			V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V5.1.0
Toyota	Auris (ADE15#) Hatchback	2AD-FHV	2.2L	03/2007+	130kW / 177HP		22465	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0
Toyota	Auris (ADE15#) Hatchback	2AD-FHV	2.2L 200MPa	03/2009+	130kW / 177HP			V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V6.1.0
Toyota	Avensis (_ T22 _) (CDT220 _) Estate / Station Wagon	1CD-FTV	2.0L HP2	10/1999 - 02/2003	81kW / 110HP		14107	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	
Toyota	Avensis (_ T22 _) (CDT220 _) Liftback / Hatchback	1CD-FTV	2.0L HP2	10/1999 - 02/2003	81kW / 110HP		14105	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	
Toyota	Avensis (_ T22 _) (CDT220 _) Saloon	1CD-FTV	2.0L HP2	10/1999 - 02/2003	81kW / 110HP		14106	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	
Toyota	Avensis (_ T22 _) (CT220 _) Estate / Station Wagon	2C-TE	2.0L V3 ROM	09/1997 - 02/2003	66kW / 90HP		8937	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	
Toyota	Avensis (_ T22 _) (CT220 _) Liftback / Hatchback	2C-TE	2.0L V3 ROM	09/1997 - 02/2003	66kW / 90HP		89232	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	
Toyota	Avensis (_ T22 _) (CT220 _) Saloon	2C-TE	2.0L V3 ROM	09/1997 - 02/2003	66kW / 90HP		8927	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	
Toyota	Avensis (_ T22 _) Estate / Station Wagon	1CD-FTV	2.0L	09/2001 - 02/2003	85kW / 115HP		28757	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	
Toyota	Avensis (_ T22 _) Liftback / Hatchback	1CD-FTV	2.0L	09/2001 - 02/2003	85kW / 115HP		28770	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	
Toyota	Avensis (_ T22 _) Saloon	1CD-FTV	2.0L	09/2001 - 02/2003	85kW / 115HP		28765	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	
Toyota	Avensis (ADT250) Hatchback	1AD-FTV	2.0L D-4D	03/2006+	93kW / 126HP		19830	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0
Toyota	Avensis (ADT251) Hatchback	2AD-FHV	2.2 D-CAT	07/2005+	130kW / 177HP		19249	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0
Toyota	Avensis (ADT251) Hatchback	2AD-FTV	2.2L TD	04/2005+	74kW / 101HP		28553	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0
Toyota	Avensis (ADT251) Hatchback	2AD-FTV	2.2 D-4D	10/2005+	110kW / 150HP		19246	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0
Toyota	Avensis (ADT270) Estate	1AD-FTV	2.0L D-4D 200MPa	02/2009+	93kW / 126HP		30883	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V5.1.0
Toyota	Avensis (ADT270) Saloon	1AD-FTV	2.0L D-4D 200MPa	02/2009+	93kW / 126HP		30877	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V5.1.0
Toyota	Avensis (ADT271) Estate	2AD-FHV	2.2L D-4D 200MPa	02/2009+	110kW / 150HP		30885	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V6.1.0
Toyota	Avensis (ADT271) Estate	2AD-FTV	2.2L D-4D 200MPa	02/2009+	130kW / 177HP		30884	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V5.1.0
Toyota	Avensis (ADT271) Saloon	2AD-FHV	2.2L D-4D 200MPa	02/2009+	110kW / 150HP		30878	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V6.1.0
Toyota	Avensis (ADT271) Saloon	2AD-FTV	2.2L D-4D 200MPa	02/2009+	130kW / 177HP		30879	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V5.1.0
Toyota	Avensis (CDT25#) Hatchback	1CD-FTV	2.0L D-4D	04/2003+	85kW / 115HP		17347	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0
Toyota	Avensis (T25) Combi / Estate	1AD-FTV	2.0L D-4D	03/2006+	93kW / 126HP		19832	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0
Toyota	Avensis (T25) Combi / Estate	1CD-FTV	2.0L D-4D	04/2003+	85kW / 116HP		17221	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0
Toyota	Avensis (T25) Combi / Estate	2AD-FHV	2.2 D-CAT	07/2005+	130kW / 177HP		19251	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0
Toyota	Avensis (T25) Combi / Estate	2AD-FTV	2.2L TD	04/2005+	74kW / 101HP		28552	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0
Toyota	Avensis (T25) Combi / Estate	2AD-FTV	2.2 D-4D	10/2005+	110kW / 150HP		19248	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0

DENSO



DST-PC

Version 6.1.0
DIESEL ENGINES

Additional
Required
Diagnostic
Cable



Manage Projects	Read and Delete Trouble Codes and Freeze Frame Data	Live Data Parameter Monitor	Perform Active Test	Utility Menu (examples: Pump- & Pilot Quantity (Detail) Learning, Injector Programming, Crank time - & A/F sensor Compensation)	Help (DST-PC Operation Manual)	Diagnosis Manual

Make	Model	Engine	Displacement	Model Year	Info									
Toyota														
Toyota	Hiace IV Box (H100) SBV (KLH-1#_2#) 4x4	2KD-FTV	2.5L D-4D	08/2001 - 08/2006	65kW / 88HP		27276	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	
Toyota	Hiace IV Box SBV (KLH-1#_2#)	2KD-FTV	2.5L D-4D	11/2001+	65kW / 88HP		16557	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	
Toyota	Hiace IV Box SBV (KLH-1#_2#)	2KD-FTV	2.5L D-4D	11/2001+	75kW / 102HP		16558	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	
Toyota	Hiace IV Box SBV (KLH-1#_2#) 4WD	2KD-FTV	2.5L D-4D	11/2001+	75kW / 102HP		19625	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	
Toyota	Hiace IV Wagon / Bus (H100) SBV (KLH-1#_2#)	2KD-FTV	2.5L D-4D	08/2001 - 08/2006	75kW / 102HP		27147	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	
Toyota	Hiace IV Wagon / Bus SBV (KLH-1#_2#)	2KD-FTV	2.5L D-4D	08/2001 - 08/2006	65kW / 88HP		16546	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	
Toyota	Hiace IV Wagon / Bus SBV (KLH-1#_2#)	2KD-FTV	2.5L D-4D	08/2001 - 08/2006	75kW / 102HP		16547	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	
Toyota	Hiace V Box SBV (KLH-1#_2#)	2KD-FTV	2.5L D-4D	09/2006+	70kW / 95HP		33640	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V5.0.0
Toyota	Hiace V Box SBV (KLH-1#_2#)	2KD-FTV	2.5L D-4D	09/2006+	86kW / 117HP		27278	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V5.0.0
Toyota	Hiace V Box SBV (KLH-1#_2#) 4x4	2KD-FTV	2.5L D-4D	09/2006+	86kW / 117HP		27279	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V5.0.0
Toyota	Hilux	2KD-FTV	2.5L	07/2001 - 08/2005				V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	
Toyota	Hilux Pickup	2KD-FTV	2.5L D-4D	06/2006+	75kW / 102HP		28515	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	
Toyota	Hilux Pickup	2KD-FTV	2.5L D-4D	12/2007+	88kW / 120HP		25452	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	
Toyota	Hilux Pickup (KUN16)	1KD-FTV	3.0L	08/2005 - 09/2006	120kW / 163HP		34586	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.1.0
Toyota	Hilux Pickup (KUN16)	1KD-FTV	3.0L D	10/2006+	120kW / 163HP		34585	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.1.0
Toyota	Hilux Pickup 4x4	1KD-FTV	3.0L D-4D	12/2007+	120kW / 163HP		25453	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.1.0
Toyota	Hilux Pickup 4x4	2KD-FTV	2.5L D-4D	08/2005+	75kW / 102HP		25198	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	
Toyota	Hilux Pickup 4x4	2KD-FTV	2.5L D-4D	12/2007+	88kW / 120HP		25451	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	
Toyota	Hilux Pickup 4x4	2KD-FTV	2.5L D-4D	12/2007+	106kW / 144HP		34943	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	
Toyota	Hilux Pickup All-wheel Drive 4x4	1KD-FTV	3.0L	08/2005 - 09/2006	120kW / 163HP		34581	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.1.0
Toyota	Land Cruiser (J12) Prado	1VD-FTV	4.5L D	02/2005+	151kW / 205HP		33691	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	
Toyota	Land Cruiser (J12) Prado (KDJ120)	1KD-FTV	3.0L D-4D	01/2007+	127kW / 173HP		22697	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0
Toyota	Land Cruiser (J12) Prado (KDJ120)	1KD-FTV	3.0L D-4D	08/2004+	122kW / 166HP		18685	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0
Toyota	Land Cruiser (J12) Prado (KDJ120)	1KD-FTV	3.0L D-4D	09/2002+	120kW / 163HP		17230	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0
Toyota	Land Cruiser (J12) Prado (KZJ12)	1KZ-TE	3.0L D-4D	09/2002+	92kW / 125HP		30469	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0
Toyota	Land Cruiser (J20) Amazon (VDJ200)	1VD-FTV	4.5L V8	01/2008+	195kW / 265HP		30453	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.1.0
Toyota	Land Cruiser (J20) Amazon (VDJ200)	1VD-FTV	4.5L V8	01/2008+	210kW / 286HP		29493	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.1.0
Toyota	Land Cruiser 100 (J10) Prado (HZJ100)	1HD-FTE	4.2L TDi 24V	01/1998 - 07/2003	150kW / 204HP		25550	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	
Toyota	Land Cruiser 100 (J10) Prado (HZJ100)	1HD-FTE	4.2L TD	01/1998+	150kW / 204HP		9560	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	
Toyota	Land Cruiser 100 (J10) Prado (HZJ105) 4x4	1HZ	4.2L D	03/1998+	96kW / 131HP		34682		N/A	N/A	N/A	N/A	N/A	
Toyota	Land Cruiser 150 (J15) Prado	1KD-FTV	3.0L D-4D	01/2010+	140kW / 190HP		843	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	
Toyota	Land Cruiser 150 (J15) Prado	1KD-FTV	3.0L D-4D	03/2010+	127kW / 173HP		33574	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	V3.0.0	
Toyota	Land Cruiser 90 (J9) Prado	1HD-FTE	4.2L TD	08/1999 - 08/2001	123kW / 167HP		20477	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	
Toyota	Land Cruiser 90 (J9) Prado	1KD-FTV	3.0L D-4D	10/2000+	120kW / 163HP		15587	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	
Toyota	Land Cruiser Flatbed / Chassis (J7) HDJ78) 4x4	1HD-FTE	4.2L TD 24V	11/2001 - 02/2007	122kW / 166HP		34678	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	
Toyota	Land Cruiser Flatbed / Chassis (J7) HDJ78) 4x4	1VD-FTV	4.5L TD 24V	03/2007+	151kW / 205HP		34683	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	
Toyota	Optimo	15B-FTE	4.1L	05/2001 - 08/2006	114kW / 153HP			Software on Special Request						
Toyota	Optimo	N04C-TQ	4.0L	08/2006 - 08/2009	110kW / 150HP			Software on Special Request						
Toyota	Optimo	N04C-TY	4.0L		110kW / 150HP			Software on Special Request						
Toyota	Previa / Estima/ Tarago (ACR3)	1CD-FTV	2.0L D-4D	03/2001+	85kW / 116HP		16025	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	V5.0.0	
Toyota	RAV4 II (XA2) 4WD	1CD-FTV	2.0L D-4D	09/2001+	85kW / 116HP		16252	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0	V2.0.0
Toyota	RAV4 III (ACA , ACE , ALA)	2AD-FHV	2.2L D-4D	03/2006+	100kW / 136HP		19296	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.1.0
Toyota	RAV4 III (ACA , ACE , ALA)	2AD-FHV	2.2L D-CAT	03/2006+	130kW / 177HP		19297	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.0.0	V4.1.0
Toyota	RAV4 III (ACA , ACE , ALA)	2AD-FTV	2.2L D-4D 200MPa	12/2008+	110kW / 150HP		31139	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V6.1.0
Toyota	RAV4 III (ACA , ACE , ALA)	2AD-FTV	2.2L D-4D 200MPa	12/2008+	110kW / 150HP		34938	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V6.1.0
Toyota	RAV4 III (ACA , ACE , ALA)	2AD-FHV	2.2L D-4D 200MPa	12/2008+	130kW / 177HP			V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V6.1.0
Toyota	Verso	1AD-FTV	2.0L D-4D 200MPa	04/2009+	93kW / 126HP		31566	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	
Toyota	Verso	2AD-FHV	2.2L D-4D 200MPa	04/2009+	110kW / 150HP		31567	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	
Toyota	Verso	2AD-FTV	2.2L D-CAT 200MPa	04/2009+	130kW / 177HP		31568	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	V4.1.0	

"N/A" (Not Applicable); This vehicle does not support these functions.

"Software on Special Request": sent e-mail to dstpc@denso.nl for instructions.

(*1) This Additional Required Diagnostic Cable is only needed when the Python interface is used (not with the DST-i interface).

(*2) Pressure Relief valve Counter Reset function is not available

Although every effort has been made to ensure the content of this coverage list is accurate we accept no responsibility for mistakes or omissions. We reserve the right to add or remove applications or functionality at our discretion without notification.

DENSO



Manage Projects

Read and Delete Trouble Codes
and Freeze Frame Data

Live Data Parameter Monitor

Perform Active Test

Utility Menu

Help
(DST-PC Operation Manual)

Diagnosis Manual

DST-PC

Version 6.1.0

PETROL ENGINES

(until December 2012)



K-Type

Make	Model	Model Code	Displacement	Engine Code	Production	Info										
------	-------	------------	--------------	-------------	------------	------	--	--	--	--	--	--	--	--	--	--








E-OBD / OBD-2

E-OBD / OBD-2	ISO9141-2									V6.1.0	V6.1.0	V6.1.0			N/A	V6.1.0	V3.1.0
E-OBD / OBD-2	ISO14230-4 KWP									V6.1.0	V6.1.0	V6.1.0			N/A	V6.1.0	V3.1.0
E-OBD / OBD-2	ISO15765-4 CAN									V6.1.0	V6.1.0	V6.1.0			N/A	V6.1.0	V3.1.0

Toyota

Toyota	AURIS	NRE150	1.33L	1NR-FE	05/2009+	74kW / 101HP	31115	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	AURIS	NRE150	1.33L	1NR-FE	01/2010+	73kW / 99HP	34982	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	AURIS	ZZE111	1.4L	4ZZ-FE	03/2007+	71kW / 97HP	22470	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	AURIS	ZZE120	1.4L	4ZZ-FE	03/2007+	71kW / 97HP	22470	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	AURIS	ZZE150	1.4L	4ZZ-FE	03/2007+	71kW / 97HP	22470	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	AURIS	ZRE151	1.6L	1ZR-FAE	05/2009+	97kW / 132HP	31116	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	AURIS	ZRE151	1.6L	1ZR-FE	03/2007+	91kW / 124HP	22469	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	AURIS	ZZE112	1.6L	3ZZ-FE				V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	AURIS	ZZE121	1.6L	3ZZ-FE				V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	AURIS	ZRE152	1.8L	2ZR-FAE	02/2009+	108kW / 147HP	31147	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	AURIS	ZRE152	1.8L	2ZR-FE	10/2006+	100kW / 136HP	24667	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	AURIS	ZWE150	1.8L	2ZR-FXE				V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	AURIS	ZZE123	1.8L	2ZZ-GE				V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	AVENSIS	ZRT270	1.6L	1ZR-FAE	02/2009+	97kW / 132HP	30880	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	AVENSIS Saloon	ZRT270	1.6L	1ZR-FAE	02/2009+	97kW / 132HP	30874	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	AVENSIS	ZZT221	1.6L	3ZZ-FE	10/2000 - 02/2003	81kW / 110HP	15515	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	AVENSIS	ZZT250	1.6L	3ZZ-FE	04/2003+	81kW / 110HP	18878	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	AVENSIS	ZZT220	1.8L	1ZZ-FE	10/2000 - 02/2003	95kW / 129HP	15518	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	AVENSIS	ZZT251	1.8L	1ZZ-FE	04/2003+	95kW / 129HP	17344	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	AVENSIS	ZRT271	1.8L	2ZR-FAE	02/2009+	108kW / 147HP	30881	V5.1.0	V5.1.0	V6.1.0		V6.1.0	V6.1.0	V6.1.0	V5.1.0	V6.1.0	
Toyota	AVENSIS Saloon	ZRT271	1.8L	2ZR-FAE	02/2009+	108kW / 147HP	30875	V5.1.0	V5.1.0	V6.1.0		V6.1.0	V6.1.0	V6.1.0	V5.1.0	V6.1.0	
Toyota	AVENSIS	AZT250	2.0L	1AZ-FE	03/2003+	114kW / 155HP	27321	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	AVENSIS	AZT270	2.0L	1AZ-FE				V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	AVENSIS	AZT220	2.0L	1AZ-FSE	10/2000 - 02/2003	110kW / 150HP	15520	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	AVENSIS	AZT250	2.0L	1AZ-FSE	04/2003+	108kW / 147HP	17345	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	AVENSIS	ZRT272	2.0L	3ZR-FAE	02/2009+	112kW / 152HP	30882	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	AVENSIS Saloon	ZRT272	2.0L	3ZR-FAE	02/2009+	112kW / 152HP	30876	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	AVENSIS	ZRT272	2.0L	3ZR-FE				V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	AVENSIS	AZT251	2.4L	2AZ-FSE	10/2003+	120kW / 163HP	17709	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	AVENSIS	AZT251	2.4L	2AZ-FSE	09/2003+	125kW / 170HP	17346	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	AVENSIS VERSO	ACM20	2.0L	1AZ-FE	08/2001+	110kW / 150HP	16026	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	AVENSIS VERSO	SXM10	2.0L	3S-FE				V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	AVENSIS VERSO	ACM20	2.4L	2AZ-FE	10/2003+	115kW / 156HP	20826	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	AYGO	KGB10	1.0L	1KR-FE	07/2005+	50kW / 68HP	18830	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	CAMRY	ACV40	2.4L	2AZ-FE	01/2006+	116kW / 158HP	20332	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	CAMRY	ACV40	2.4L	2AZ-FE	01/2006+	123kW / 167HP	34837	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	CAMRY	GSV40	3.5L	2GR-FE				V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	CELICA	ZZT230	1.8L	1ZZ-FE	11/1999+	105kW / 143HP	14169	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	CELICA	ZZT231	1.8L	2ZZ-GE	11/1999+	141kW / 192HP	14534	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	COROLLA Saloon	NRE150	1.33L	1NR-FE	10/2008+	74kW / 101HP	31148	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	COROLLA	ZZE111	1.4L	4ZZ-FE	02/2000 - 01/2002	71kW / 97HP	14692	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	COROLLA Compact/Hatchback	ZZE111	1.4L	4ZZ-FE	02/2000 - 01/2002	71kW / 97HP	14689	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	COROLLA Liftback	ZZE111	1.4L	4ZZ-FE	02/2000 - 01/2002	71kW / 97HP	14691	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	COROLLA	ZZE120	1.4L	4ZZ-FE	01/2000+	71kW / 97HP	16373	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	COROLLA Estate/Combi	ZZE120	1.4L	4ZZ-FE	01/2002+	71kW / 97HP	16378	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	COROLLA Saloon	ZZE120	1.4L	4ZZ-FE	08/2002+	71kW / 97HP	16381	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	COROLLA	ZZE150	1.4L	4ZZ-FE				V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	COROLLA	ZRE151	1.6L	1ZR-FAE				V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	COROLLA Saloon	ZRE151	1.6L	1ZR-FE	01/2007+	91kW / 124HP	30716	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	COROLLA Saloon	ZRE151	1.6L	1ZR-FE	01/2009+	97kW / 132HP	31149	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	COROLLA	ZZE112	1.6L	3ZZ-FE	02/2000 - 01/2002	81kW / 110HP	14695	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	COROLLA Compact/Hatchback	ZZE112	1.6L	3ZZ-FE	02/2000 - 01/2002	81kW / 110HP	14690	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	COROLLA Liftback	ZZE112	1.6L	3ZZ-FE	02/2000 - 01/2002	81kW / 110HP	14694	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	COROLLA	ZZE121	1.6L	3ZZ-FE	02/2000 - 01/2002	81kW / 110HP	16374	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	COROLLA Estate/Combi	ZZE121	1.6L	3ZZ-FE	01/2002+	81kW / 110HP	16379	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	COROLLA Saloon	ZZE121	1.6L	3ZZ-FE	08/2002+	81kW / 110HP	16382	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	COROLLA	ZRE152	1.8L	2ZR-FAE	09/2006+	106kW / 144HP	5870	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	COROLLA 4WD	ZRE152	1.8L	2ZR-FAE	09/2006+	98kW / 133HP	5872	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	COROLLA Hatchback	ZRE152	1.8L	2ZR-FE	05/2007+	100kW / 136HP	34646	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	COROLLA Saloon	ZRE152	1.8L	2ZR-FE	05/2007+	100kW / 136HP	34643	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	COROLLA	ZWE150	1.8L	2ZR-FXE				V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	COROLLA	ZZE123	1.8L	2ZZ-GE	01/2002+	141kW / 192HP	16375	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	COROLLA	ZZE123	1.8L	2ZZ-GE	02/2005+	165kW / 224HP	19252	V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	COROLLA VERSO	ZGR20	1.6L	1ZR-FAE				V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	COROLLA VERSO	ZNR10	1.6L	3ZZ-FE				V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	COROLLA VERSO	ZZE121	1.6L	3ZZ-FE	01/2002 - 05/2004	81kW / 110HP	16384	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	COROLLA VERSO	ZZE121	1.6L	3ZZ-FE	04/2004+	81kW / 110HP	18039	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	COROLLA VERSO	ZNR11	1.8L	1ZZ-FE				V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	COROLLA VERSO	ZZE122	1.8L	1ZZ-FE	01/2002 - 05/2004	99kW / 135HP	16514	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	COROLLA VERSO	ZZE122	1.8L	1ZZ-FE	04/2004+	95kW / 129HP	18040	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	COROLLA VERSO All-wheel Drive	ZZE122	1.8L	1ZZ-FE	10/2002 - 02/2004	99kW / 135HP	24634	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	COROLLA VERSO	ZGR21	1.8L	2ZR-FAE				V5.1.0	V5.1.0	V5.1.0						V5.1.0	
Toyota	HIACE	TRH201	2.7L	2TR-FE	01/2005+	111kW / 151HP	30493	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	HIACE	TRH203	2.7L	2TR-FE	01/2005+	111kW / 151HP	40483	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	HIACE	TRH213	2.7L	2TR-FE	01/2005+	111kW / 151HP	40483	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	HIACE	TRH221	2.7L	2TR-FE	01/2005+	111kW / 151HP	30493	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	HIACE	TRH223	2.7L	2TR-FE	01/2005+	111kW / 151HP	40483	V6.0.0	V6.0.0	V6.0.0						V6.0.0	
Toyota	HIACE	RCH13	2.7L	3RZ-FE	04/1998 - 11/200												



	Manage Projects
	Read and Delete Trouble Codes and Freeze Frame Data
	Live Data Parameter Monitor
	Perform Active Test
	Utility Menu
	Help (DST-PC Operation Manual)
	Diagnosis Manual

Make	Model	Model Code	Displacement	Engine Code	Production	Info	K-Type	Man	Reas and	Live	Perf	Utilit	Help (OS	Diag
Toyota														
Toyota	HILUX	TGN10	2.0L	1TR-FE				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	HILUX	TGN15	2.0L	1TR-FE				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	HILUX	TGN11	2.7L	2TR-FE	08/2005+	118kW / 160HP	28483	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	HILUX	TGN16	2.7L	2TR-FE	08/2005+	118kW / 160HP	28483	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	HILUX	TGN26	2.7L	2TR-FE	08/2005+	118kW / 160HP	28483	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	HILUX	TGN36	2.7L	2TR-FE	08/2005+	118kW / 160HP	28483	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	HILUX All-wheel Drive	TGN11	2.7L	2TR-FE	08/2005+	118kW / 160HP	28484	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	HILUX All-wheel Drive	TGN16	2.7L	2TR-FE	08/2005+	118kW / 160HP	28484	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	HILUX All-wheel Drive	TGN26	2.7L	2TR-FE	08/2005+	118kW / 160HP	28484	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	HILUX All-wheel Drive	TGN36	2.7L	2TR-FE	08/2005+	118kW / 160HP	28484	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	HILUX	GGN15	4.0L	1GR-FE	08/2005+	175kW / 238HP	28485	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	HILUX	GGN25	4.0L	1GR-FE	08/2005+	175kW / 238HP	28485	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	HILUX	GGN35	4.0L	1GR-FE	08/2005+	175kW / 238HP	28485	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	HILUX All-wheel Drive	GGN15	4.0L	1GR-FE	08/2005+	175kW / 238HP	28486	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	HILUX All-wheel Drive	GGN25	4.0L	1GR-FE	08/2005+	175kW / 238HP	28486	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	HILUX All-wheel Drive	GGN35	4.0L	1GR-FE	08/2005+	175kW / 238HP	28486	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	IQ	KGJ10	1.0L	1KR-FE	01/2009+	50kW / 68HP	31142	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	IQ	NGJ10	1.33L	1NR-FE	01/2009+	69kW / 94HP	5786	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	IQ	NGJ10	1.33L	1NR-FE	01/2009+	72kW / 98HP	31143	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	LAND CRUISER	TRJ150	2.7L	2TR-FE				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	LAND CRUISER	TRJ155	2.7L	2TR-FE				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	LAND CRUISER	VZJ90	3.4L	5VZ-FE	04/1996+	131kW / 178HP	5695	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	LAND CRUISER	VZJ95	3.4L	5VZ-FE	04/1996+	131kW / 178HP	5695	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	LAND CRUISER	GRJ120	4.0L	1GR-FE	09/2002 - 08/2004	179kW / 243HP	25572	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	LAND CRUISER	GRJ125	4.0L	1GR-FE	09/2002 - 08/2004	179kW / 243HP	25572	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	LAND CRUISER	GRJ150	4.0L	1GR-FE	09/2002 - 08/2004	179kW / 243HP	25572	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	LAND CRUISER	GRJ120	4.0L	1GR-FE	01/2003+	183kW / 249HP	17229	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	LAND CRUISER	GRJ125	4.0L	1GR-FE	01/2003+	183kW / 249HP	17229	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	LAND CRUISER	GRJ150	4.0L	1GR-FE	01/2003+	183kW / 249HP	17229	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	LAND CRUISER	GRJ150	4.0L	1GR-FE	01/2010+	183kW / 249HP	33586	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	LAND CRUISER	GRJ150	4.0L	1GR-FE	01/2010+	205kW / 279HP	33589	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	LAND CRUISER	GRJ150	4.0L	1GR-FE	01/2010+	207kW / 282HP	837	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	LAND CRUISER STATION WAGON	GRJ200	4.0L	1GR-FE				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	LAND CRUISER STATION WAGON 4x4	UZJ100	4.7L	2UZ-FE	03/1998+	165kW / 224HP	34691	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	LAND CRUISER STATION WAGON	UZJ100	4.7L	2UZ-FE	03/1998+	173kW / 235HP	9559	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	LAND CRUISER STATION WAGON	UZJ100	4.7L	2UZ-FE	03/1998+	175kW / 238HP	17320	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	LAND CRUISER STATION WAGON	UZJ200	4.7L	2UZ-FE	11/2007+	202kW / 275HP	34692	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	LAND CRUISER STATION WAGON	UZJ200	4.7L	2UZ-FE	01/2008+	212kW / 288HP	29492	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	LAND CRUISER STATION WAGON	UZJ200	4.7L	2UZ-FE	01/2010+	175kW / 238HP	33591	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	LAND CRUISER STATION WAGON	URJ200	5.7L	3UR-FE				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	PICNIC	ACM20	2.0L	1AZ-FE	05/2001 - 08/2006	110kW / 150HP	25318	V5.1.0	V5.1.0	V5.1.0			V5.1.0	
Toyota	PICNIC	SXM10	2.0L	3S-FE	05/1996 - 12/2001	94kW / 128HP	7919	V5.1.0	V5.1.0	V5.1.0			V5.1.0	
Toyota	PICNIC	SXM10	2.0L	3S-FE	01/2001 - 12/2001	90kW / 122HP	16165	V5.1.0	V5.1.0	V5.1.0			V5.1.0	
Toyota	PICNIC	ACM20	2.4L	2AZ-FE	11/2003 - 08/2006	115kW / 156HP	25317	V5.1.0	V5.1.0	V5.1.0			V5.1.0	
Toyota	PICNIC 4x4	ACM20	2.4L	2AZ-FE	11/2003 - 08/2006	115kW / 156HP	25354	V5.1.0	V5.1.0	V5.1.0			V5.1.0	
Toyota	PREVIA / ESTIMA	ACR30	2.4L	2AZ-FE	08/2000+	115kW / 156HP	14888	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	PRIUS	NHW11	1.5L	1NZ-FXE	05/2000 - 01/2004	53kW / 72HP	15651	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	PRIUS	NHW20	1.5L	1NZ-FXE	08/2003+	57kW / 78HP	17711	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	PRIUS	ZVW30	1.8L	2ZR-FXE	01/2009+	73kW / 99HP	31134	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	PRIUS PHV	ZVW35	1.8L	2ZR-FXE				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	RAV4	ZCA25	1.8L	1ZZ-FE				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	RAV4	ZCA26	1.8L	1ZZ-FE				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	RAV4	ACA20	2.0L	1AZ-FE	03/2006+	112kW / 152HP	19295	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	RAV4	ACA21	2.0L	1AZ-FE	03/2006+	112kW / 152HP	19295	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	RAV4	ACA30	2.0L	1AZ-FE	03/2006+	112kW / 152HP	19295	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	RAV4	ZSA30	2.0L	3ZR-FAE				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	RAV4	ZSA35	2.0L	3ZR-FAE				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	RAV4	ACA31	2.4L	2AZ-FE	11/2005+	125kW / 170HP	20645	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	RAV4	ACA33	2.4L	2AZ-FE	11/2005+	125kW / 170HP	20645	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	RAV4	ACA38	2.4L	2AZ-FE	11/2005+	125kW / 170HP	20645	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	RAV4	ACA38	2.4L	2AZ-FE	11/2005+	125kW / 170HP	20645	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	RAV4 4WD	ACA31	2.4L	2AZ-FE	11/2005+	125kW / 170HP	5806	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	RAV4 4WD	ACA33	2.4L	2AZ-FE	11/2005+	125kW / 170HP	5806	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	RAV4 4WD	ACA38	2.4L	2AZ-FE	11/2005+	125kW / 170HP	5806	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	RAV4 4WD	ACA38	2.4L	2AZ-FE	11/2005+	125kW / 170HP	5806	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	RAV4	GSA33	3.5L	2GR-FE				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	URBAN CRUISER	NSP110	1.33L	1NR-FE	04/2010+	73kW / 99HP	848	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	URBAN CRUISER	NSP110	1.33L	1NR-FE	04/2009+	74kW / 101HP	32024	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	YARIS / ECHO / VITZ	KSP90	1.0L	1KR-FE	01/2006+	51kW / 69HP	19254	V5.1.0	V5.1.0	V5.1.0			V5.1.0	
Toyota	YARIS / ECHO / VITZ	SCP10	1.0L	1SZ-FE	03/2003+	48kW / 65HP	17569	V5.1.0	V5.1.0	V5.1.0			V5.1.0	
Toyota	YARIS / ECHO / VITZ	SCP10	1.0L	1SZ-FE	04/1999+	50kW / 68HP	10466	V5.1.0	V5.1.0	V5.1.0			V5.1.0	
Toyota	YARIS / ECHO / VITZ	NSP90	1.33L	1NR-FE	03/2009+	74kW / 100HP	30845	V5.1.0	V5.1.0	V5.1.0			V5.1.0	
Toyota	YARIS / ECHO / VITZ	NCP10	1.3L	2NZ-FE	11/1999+	63kW / 86HP	14287	V5.1.0	V5.1.0	V5.1.0			V5.1.0	
Toyota	YARIS / ECHO / VITZ	NCP15	1.3L	2NZ-FE	11/1999+	63kW / 86HP	14287	V5.1.0	V5.1.0	V5.1.0			V5.1.0	
Toyota	YARIS / ECHO / VITZ	NCP90	1.3L	2NZ-FE	11/2005+	63kW / 86HP	7761	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	YARIS / ECHO / VITZ	NCP92	1.3L	2NZ-FE	11/2005+	63kW / 86HP	7761	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	YARIS / ECHO / VITZ	NCP90	1.3L	2NZ-FE	08/2007+	64kW / 87HP	5884	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	YARIS / ECHO / VITZ	NCP92	1.3L	2NZ-FE	08/2007+	64kW / 87HP	5884	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	YARIS / ECHO / VITZ	SCP12	1.3L	2SZ-FE	04/2002+	64kW / 87HP	17319	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	YARIS / ECHO / VITZ	SCP13	1.3L	2SZ-FE	04/2002+	64kW / 87HP	17319	V5.1.0	V5.1.0	V5.1.0			V5.1.0	
Toyota	YARIS / ECHO / VITZ	SCP90	1.3L	2SZ-FE	01/2006+	64kW / 87HP	19256	V5.1.0	V5.1.0	V6.1.0	V6.1.0		V5.1.0	
Toyota	YARIS / ECHO / VITZ	NCP13	1.5L	1NZ-FE	01/2003+	77kW / 105HP	17705	V5.1.0	V5.1.0	V5.1.0			V5.1.0	
Toyota	YARIS / ECHO / VITZ	NCP13	1.5L	1NZ-FE	04/2001+	78kW / 106HP	15984	V5.1.0	V5.1.0	V5.1.0			V5.1.0	
Toyota	YARIS / ECHO / VITZ	NCP91	1.5L	1NZ-FE	11/2005+	80kW / 109HP	30010	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	YARIS / ECHO / VITZ	NCP93	1.5L	1NZ-FE	11/2005+	80kW / 109HP	30010	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	YARIS / ECHO / VITZ	ZSP90	1.8L	2ZR-FE	01/2007+	98kW / 133HP	22475	V5.1.0	V5.1.0	V5.1.0			V5.1.0	

DENSO



DST-PC

Version 6.1.0
PETROL ENGINES
(until December 2012)



K-Type

Manage Projects	Read and Delete Trouble Codes and Freeze Frame Data	Live Data Parameter Monitor	Perform Active Test	Utility Menu	Help (DST-PC Operation Manual)	Diagnosis Manual

Make	Model	Model Code	Displacement	Engine Code	Production	Info	K-Type							
Toyota														
Toyota	YARIS Verso / ECHO Verso	NCP20	1.3L	2NZ-FE				V5.1.0	V5.1.0	V5.1.0			V5.1.0	
Toyota	YARIS Verso / ECHO Verso	NCP22	1.3L	2NZ-FE	11/1999+	62kW / 84HP	17706	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	YARIS Verso / ECHO Verso	NCP22	1.3L	2NZ-FE	11/1999+	63kW / 86HP	13663	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Toyota	YARIS Verso / ECHO Verso	NCP21	1.5L	1NZ-FE	05/2003+	77kW / 105HP	17707	V5.1.0	V5.1.0	V5.1.0			V5.1.0	
Toyota	YARIS Verso / ECHO Verso	NCP21	1.5L	1NZ-FE	05/2003+	78kW / 106HP	15633	V5.1.0	V5.1.0	V5.1.0			V5.1.0	
Toyota	YARIS Verso / ECHO Verso	NCP25	1.5L	1NZ-FE				V5.1.0	V5.1.0	V5.1.0			V5.1.0	

Lexus														
Lexus	ES240	ACV40	2.4L	2AZ-FE				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	ES350	GSV40	3.5L	2GR-FE	01/2007 - 12/2010	45205		V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	GS300	GRS190	3.0L	3GR-FE	04/2005+	183kW / 249HP	18773	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	GS300	GRS190	3.0L	3GR-FSE				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	GS350	GRS196	3.5L	2GR-FSE				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	GS430	UZS190	4.3L	3UZ-FE	11/2000 - 03/2005	208kW / 283HP	15577	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	GS430	UZS190	4.3L	3UZ-FE	04/2005+	208kW / 283HP	18774	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	GS450h	GWS191	3.5L	2GR-FSE	02/2006+	218kW / 296HP	19338	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	GS460	URS190	4.6L	1UR-FE				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	GS460	URS190	4.6L	1UR-FSE	05/2008+	218kW / 296HP	27554	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	GX460	URJ150	4.6L	1UR-FE				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	IS F	USE20	5.0L	2UR-GSE	03/2008+	311kW / 423HP	24545	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	IS200	GXE10	2.0L	1G-FE	04/1999+	114kW / 155HP	10281	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	IS200	GXE10	2.0L	1G-FE	10/2002+	114kW / 155HP	17115	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	IS250	GSE20	2.5L	4GR-FSE	10/2005+	153kW / 208HP	19066	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	IS250C	GSE20	2.5L	4GR-FSE	10/2005+	153kW / 208HP	31715	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	IS300	GSE22	3.0L	3GR-FE				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	IS300	JCE10	3.0L	2JZ-GJE	10/2001+	157kW / 213HP	16321	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	IS300C	GSE22	3.0L	3GR-FE				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	IS350	GSE21	3.5L	2GR-FSE				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	LS430	UCF30	4.3L	3UZ-FE	10/2000+	207kW / 282HP	15578	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	LS460	USF40	4.6L	1UR-FE	05/2008+	255kW / 347HP	28197	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	LS460	USF40	4.6L	1UR-FSE	04/2006+	280kW / 381HP	19760	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	LS460	USF41	4.6L	1UR-FE	05/2008+	255kW / 347HP	28197	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	LS460	USF41	4.6L	1UR-FSE	04/2006+	280kW / 381HP	19760	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	LS460	USF45	4.6L	1UR-FSE	04/2006+	280kW / 381HP	19760	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	LS460	USF46	4.6L	1UR-FSE	04/2006+	280kW / 381HP	19760	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	LS460 AWD	USF40	4.6L	1UR-FSE	12/2008+	270kW / 367HP	33013	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	LS460 AWD	USF41	4.6L	1UR-FSE	12/2008+	270kW / 367HP	33013	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	LS460 AWD	USF45	4.6L	1UR-FSE	12/2008+	270kW / 367HP	33013	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	LS460 AWD	USF46	4.6L	1UR-FSE	12/2008+	270kW / 367HP	33013	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	LS460 AWD	USF40	4.6L	1UR-FSE	12/2008+	280kW / 381HP	28598	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	LS460 AWD	USF41	4.6L	1UR-FSE	12/2008+	280kW / 381HP	28598	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	LS460 AWD	USF45	4.6L	1UR-FSE	12/2008+	280kW / 381HP	28598	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	LS460 AWD	USF46	4.6L	1UR-FSE	12/2008+	280kW / 381HP	28598	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	LS600h	UVF45	5.0L	2UR-FSE	08/2007+	290kW / 394HP	24546	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	LS600h	UVF46	5.0L	2UR-FSE	08/2007+	290kW / 394HP	24546	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	LX570	URJ201	5.7L	3UR-FE				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	RX270	AGL10	2.7L	1AR-FE				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	RX300	GSU35	3.5L	2GR-FE				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	RX350	GGL15	3.5L	2GR-FE	04/2009+	204kW / 277HP	32194	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	RX400h	IMHU38	3.3L	3MZ-FE				V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	RX450h	GYL10	3.5L	2GR-FXE	04/2009+	183kW / 249HP	33014	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	RX450h AWD	GYL15	3.5L	2GR-FXE	04/2009+	183kW / 249HP	31710	V6.0.0	V6.0.0	V6.0.0			V6.0.0	
Lexus	SC430	UZZ40	4.3L	3UZ-FE	08/2001+	210kW / 286HP	15860	V6.0.0	V6.0.0	V6.0.0			V6.0.0	

Although every effort has been made to ensure the content of this coverage list is accurate we accept no responsibility for mistakes or omissions. We reserve the right to add or remove applications or functionality at our discretion without notification.